

This exploded perspective view shows the backpack 10 and its associated components. The backpack 10 features a main body with a top lid and two large front pockets. A telescopic pole 30 is shown in its retracted state, with sections 4, 40, and 42. The pole is connected to a bracket 60 via a pin 61 and a sleeve 62. A strap 20 is attached to the top of the backpack and the pole. Other components include a base plate 21, a strap end 22, a strap connector 23, a strap end 24, a strap end 27, a strap end 71, a strap end 77, a strap end 84, a strap end 85, a strap end 90, and a strap end 91.

FIG. 1

FIG. 2




FIG. 3




FIG. 4




FIG. 5




FIG. 6




FIG. 7




FIG. 8






FIG. 9




FIG. 10

FIG. 11




FIG. 11